

Kawasaki Vulcan 900 Custom

2007-



SUPPLEMENTARY MANUAL

for SH-K06

REMOVE THE SEAT.
REMOVE THE LEFT FRAME COVER
BELLOW THE MAIN SEAT.



PLUG SPEEDOHEALER CONNECTORS
IN-LINE WITH THE VEHICLE SPEED
SENSOR (VSS) CONNECTORS.
(BLACK, 3-POLE CONNECTORS
LOCATED BETWEEN THE ENGINE BLOCK AND THE FRAME)



RECOMMENDED POSITION
FOR SPEEDOHEALER.



Kawasaki Vulcan 900 Custom 2007-



TYPICAL POSITION
FOR TSM SWITCH.

