Yamaha MT-10/FZ-10

SUPPLEMENTARY MANUAL

At first, please locate the **ABS unit**. See images on the second page.

1) Find, and cut the **White/Yellow** (speed signal) wire at the ABS unit connector.

This is a white wire with thin yellow stripe. Check on the first picture.

- 2) Splice the **White SH** wire to the White/Yellow wire end, which is at the ABS connector side.
- 3) Splice the **Green SH** wire to the White/Yellow wire end, which is at the wiring harness side.
- 4) Splice the **Black SH** wire to chassis ground, or the negative battery terminal.
- 5) Splice the **Red SH** wire to any +12V switched power lead (e.g. around the fusebox), or to the **Red/Black** (switched +12V) wire at the ABS connector

When the installation is done, do the SH signal test procedure as follows:

- Have the ignition key OFF.
- Press SEL and keep it depressed while you turn the ignition ON.
 [t] (test) is now indicated. Release the button.
 Check: The speedometer should indicate a steady number other than 0.
- Move the bike back and forth so both wheels are turning.
 Check: [t] should be blinking as the wheels turn.

Note: [t] appears on the display like an [E] without the top horizontal bar.



