



# **SUPPLEMENTARY MANUAL**

for GPX-S01

**REMOVE THE MAIN SEAT.  
REMOVE THE FRONT AND MIDDLE  
BLACK FRAME COVERS  
AT LEFT SIDE.**



**REMOVE THE KNOB OF FUEL TAP.  
LIFT UP OR REMOVE THE  
FUEL TANK.**



**PLUG GPX CONNECTORS IN-LINE  
WITH THE SPEED SENSOR  
CONNECTORS.**

**(BLACK, 3-POLE CONNECTORS AT LEFT SIDE  
NEAR MAIN RELAY)**



# Suzuki GSF1200 Bandit

2001-2006



CONNECT GPX BLACK/GREEN WIRE  
TO  
BLACK/BLUE WIRE OF ECU/ECM  
UNIT.

(BLACK, 8-POLE CONNECTOR  
AT LEFT SIDE BELOW THE REAR FAIRING)



TYPICAL POSITION FOR THE  
GEAR INDICATOR.

